

| Victor 88C Specifications | | |
|---------------------------|-------------------------------------|----------------|
| Basic Function | Range | Basic accuracy |
| | 200mV/2V/20V/200V/1000V | ±(0.5%+3) |
| | 2V/20V/200V/750V | |
| AC Voltage | 200mV/2V/20V/200V/750V | ±(0.8%+5) |
| | 20uA/200uA/20mA/200mA/2A/20A | |
| | 20mA/200mA/20A | |
| DC Current | 2mA/20mA/200mA/20A | ±(0.8%+3) |
| | 200mA/2A/20A | |
| | 20mA/200mA/20A | |
| AC Current | 2mA/20mA/200mA/20A | ±(1.0%+5) |
| | 200Ω/2kΩ/20kΩ/200kΩ/2MΩ/200MΩ | |
| Resistance | 200Ω/2kΩ/20kΩ/200kΩ/2MΩ/20MΩ/2000MΩ | ±(0.8%+3) |
| | 20nF/2uF/200uF | |
| Capacitance | 20nF/200nF/2uF/20uF/200uF | ±(2.5%+20) |
| | 2kHz/200kHz | |
| Frequency | 2kHz/20kHz/200kHz/2000kHz/10MHz | ±(0.5%+4) |
| Inductance | 2mH/20mH/200mH/2H/20H | ±(2.5%+20) |
| Celsius | (-40~1000)°C | ±(1.0%+4) |

| Special Function | |
|----------------------------|--------------|
| Diode test | √ |
| Continuity buzzer | √ |
| Low battery indication | √ |
| Data Hold | √ |
| Auto power off | √ |
| Backlight | √ |
| Function protection | √ |
| Restorable Fuse protection | √ |
| Shock proof protection | √ |
| Input impedance | 10MΩ |
| Sampling rate | 3 times/s |
| AC Frequency response | 40~400Hz |
| Operation way | Manual range |
| Max. Display | 1999 |
| LCD size | 65×45mm |
| Battery | 9V(6F22) |